



## Hardware Setup



1. With both units powered off Connect the **USB** and **VGA** cables to the AudioReQuest or IMS.
2. Connect the USB and VGA cables to the TS.15
3. Power on both units

### Wall Mounting



Picture frame style mounting holes (red)  
6<sup>3</sup>/<sub>16</sub>" between holes  
5<sup>1</sup>/<sub>16</sub>" maximum screw head diameter  
VESA Compliant mounting holes (green)  
Depth of screen - 3<sup>1</sup>/<sub>4</sub>"

## Software Setup

### Version 2.2.6 and 2.2.7 Enhanced Touchpanel

1. Using the IR Remote or Java Remote, select Menu
2. Navigate to **Settings>Video Settings>Screen Selection**
3. Choose **Enhanced Touchpanel**
4. Select **OK**
5. The unit will prompt you to reboot now or later, choose one.
6. Upon reboot, your TS.15 will be configured to control the AudioReQuest utilizing the Enhanced Touchpanel

### Serious Play Media Manager

1. Access the unit's webserver by entering its IP address in your web browser
2. Click **SETTINGS** on the bottom of the page
3. Select **GUI THEME** in the drop-down menu
4. On the **GUI THEME** page, choose Serious Play Media Manager
5. The unit will inform you that it requires a reboot
6. To reboot, select **FUNCTIONS** in the drop-down menu
7. On the Functions page, choose Reboot and hit OK.

### Serious Play Enhanced Touchpanel

1. Access the unit's webserver by entering its IP address in your web browser
2. Click **SETTINGS** on the bottom of the page
3. Select **GUI THEME** in the drop-down menu
4. On the **GUI THEME** page, choose Enhanced Touchpanel
5. The unit will inform you that it requires a reboot
6. To reboot, select **FUNCTIONS** in the drop-down menu
7. On the Functions page, choose Reboot and hit OK.

### iQ Intelligent Media Server

1. Access the unit's webserver by entering its IP address in your web browser
2. Click **IQ CONFIGURATION** on the bottom of the page
3. In the drop-down menu at the top of the page, select **ROOMS**
4. Drag the Master Panel in to the desired room and it will configure itself from there

## Calibration

### Version 2.2.6 and 2.2.7

1. Access the unit's webserver by entering its IP address in your web browser
2. Click on **Settings** and scroll to the bottom of the page
3. Under the Diagnostics section, Click **CALIBRATE** and follow the instructions on the touchpanel

### Serious Play and iQ

1. Access the unit's webserver by entering its IP address in your web browser
2. In the drop-down menu at the top of the page, select **FUNCTIONS**
3. Click on **CALIBRATE TS12/TS15** and follow the instructions on the touchpanel
4. When you've completed the calibration, select **OK** for "Please visit your touchpanel for calibration."